


# SerialSniffer Hardware Adapter

SerialSniffer is designed to record the data which is transferred on a serial link between two devices. The first possibility is to open up the serial link and connect SerialSniffer between the two devices :




external device #1

SerialSniffer

external device #2


The second possibility is to connect SerialSniffer "parallel" to the existing serial link using a hardware adapter. This solution prevents the serial connection from being influenced by SerialSniffer



external device #1

external device #2

SerialSniffer



The schematic diagram can be found at the right.

more infos :  
- <http://www.flache.de>  
- [shareware@flache.de](mailto:shareware@flache.de)  
last changed : 23.05.2001